



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAY 13R: Turn right heading 160° as soon as possible after take-off, but no later than 0.6 DME outbound on the I-DPX Localizer southeast course, then intercept and climb via the CVE R-139 and expect vector to appropriate route. Maintain 5,000 feet and expect filed altitude 10 minutes after departure.

ABILENE TRANSITION (LOVE2.ABI): From over TTT VOR/DME via TTT R-250 to PODDE INT, then via MQP R-081 to MQP VORTAC, then via MQP R-253 and ABI R-071 to ABI VORTAC.

BOOMR TRANSITION (LOVE2.BOOMR): (For aircraft inbound to Lubbock Terminal Area.) From over TTT VOR/DME via TTT R-275 to MANKI INT, then via GTH R-119 to OWING INT, then via LBB R-085 to BOOMR INT.

CHILDRESS TRANSITION (LOVE2.CDS): From over TTT VOR/DME via TTT R-285 to SCABI INT, then via CDS R-127 to CDS VORTAC.

CORONA TRANSITION (LOVE2.CNX): From over TTT VOR/DME via TTT R-264 to KIRST INT, then via LBB R-102 to LBB VORTAC, then via LBB R-272 and CNX R-088 to CNX VORTAC.

GUTHRIE TRANSITION (LOVE2.GTH): From over TTT VOR/DME via TTT R-275 to MANKI INT, then via GTH R-119 to GTH VORTAC.

LUBBOCK TRANSITION (LOVE2.LBB): From over TTT VOR/DME via TTT R-264 to KIRST INT, then via LBB R-102 to LBB VORTAC.

MILLSAP TRANSITION (LOVE2.MQP): From over TTT VOR/DME via TTT R-250 to PODDE INT, then via MQP R-081 to MQP VORTAC.

PANHANDLE TRANSITION (LOVE2.PNH): From over TTT VOR/DME via TTT R-285 to SCABI INT, then via CDS R-127 to CDS VORTAC, then via CDS R-297 and PNH R-118 to PNH VORTAC.

PODDE TRANSITION (LOVE2.PODDE): (ATC assigned.) From over TTT VOR/DME via TTT R-250 to PODDE INT.

TEXICO TRANSITION (LOVE2.TXO): From over TTT VOR/DME via TTT R-264 to KIRST INT, then via LBB R-102 to LBB VORTAC, then via LBB R-305 and TXO R-124 to TXO VORTAC.

TUCUMCARI TRANSITION (LOVE2.TCC): From over TTT VOR/DME via TTT R-275 to MANKI INT, then via GTH R-119 to GTH VORTAC, then via GTH R-288 and TCC R-105 to TCC VORTAC.

SC-2, 03 JUL 2008 to 31 JUL 2008

SC-2, 03 JUL 2008 to 31 JUL 2008